○ LiveCore[™] Output Expander 32 - 4K - Ref. LOE032-4K


Expansion module gives 4 additional Program outputs and 1 Operator/Aux output for linkable **LiveCore™** units





LiveCore[™] Output Expander 32-4K at a glance

- 4 Program outputs
- Output format up 4K 30Hz 4:4:4, 4K 60Hz 4:2:0 and four quadrant 4K 60Hz 4:4:4
- 1 independent Operator/Aux output
- Full Preview of any sources of the linked chassis (Preview/Mosaic/ Monitoring)
- Customization of monitoring layouts/Aux output (up to 8 templates stored)
- ▶ 4 true-Seamless scaled layers + 1 native background per output
- Advanced Layer Management
- Rotation capability in output (90 degrees)
- Outstanding visual effects
- Ruggedized and heavy duty design
- Additive modularity: compatible with SMX12x4, ASC1602-4K, ASC3204-4K, ASC4806-4K



Up to 4 independent true-Seamless scaled layers are available per screen, offering the capability to control each layer individually in time and transition.

To control the LOE032-4K:

The LOE032-4K is controlled through the LiveCore ${}^{\rm TM}$ device it is linked to:

- Web-Based Remote Control Software (Web RCS)
- ▶ VCR300: Vertige[™]
- SB124-T: Control Box
- ► SB-80: Shot Box
- Modules Crestron: 2 or 3-series*

AMX's Modules*

Key features

4 outputs with 5 output plugs

- Universal analog (HD15 & DVI-A)
- DVI-I (DVI Dual Link available on outputs #1 and #3)
- 3G/HD/SD-SDI
- 3G-SDI Optical SFP module cage

Features & Effects

- Up to 4 true-Seamless scaled layers per screen
- Independent Native Background
- 100 nonvolatile memory slots for frames and logos
- Frames and Logos: fully resizable
- True A/B mix
- Output capability up to 2560x1600 and 4K
- Customizable 5th output with 4-display options: Full Preview, Live Mosaic, Monitoring and Recording
- Display configurations: Mixer, Hybrid, Hard Edge & Soft Edge
- Additive modularity: Combine one linkable LiveCore[™] unit with one LOE032-4K to share/add inputs & outputs up to 12x8+2
- Layer border: Edge/Smooth/Shadow/Smooth Edge (Edge: color/width/height)
- New toolbox for layers: Transitions, Effects, Speed, Timing, Faders, Strobe, Mirror,...
- Numerous effects: Cut, Dissolve, Slide, Wipe, Stretch, Circle, Depth, Flip, Flying Curve, Background Cut, Transparency, Luma/Chroma Key, DSK, Cut and Fill
- Web-based Remote Control Software for multiple users: Web RCS
- Remote tools
- Remote Services


Options

- OPT-SPS: Swappable Power Supply
- ▶ OPT Link: Replacement of LiveCore™ Link Cable (spare)
- OPT-KIT3xLINK: Set of 3 LiveCore™ Link Cables
- SPU001: Secure Power Unit
- UP-LOE032-4K : 4K processing upgrade for LOE032-4K to LOE048-4K

LOE048

*Available on www.analogway.com





In addition to its four main outputs, LiveCore™ Output Expander 32 - 4K - Ref. LOE032-4K features an independent Dual-Link output for monitoring purposes. This output offers versatile and customizable display options, ensuring effective and flawless show control.

All images are live and can be labeled through the Web Remote Control Software. Additional information on each source is also available directly on the live video windows.




Dimensions: Supplied with: ▶ D 21.41"x W 17.51" x H 6.97" ▶ 1 x Power supply cord ("Rack ears" not included) ▶ 1 x OPT-KIT3xLINK D 544 mm x W 444.8 mm x H 177 mm ("Rack ears" not included) Weight: ▶ 18.4 Kgs ▶ 1 x Quick Start Guide* ▶ 40.56 lbs **Power Supply:**

100-240 VAC ; 4.8A ; 50/60Hz ; 285 W

- ▶ 1 x 1,8m long RJ45 cable
- ▶ 1 x MCO 10 pin connector
- ▶ 1 x Rack mount kit (front ears and rear support)

Warranty: 3 –year warranty on parts and labor back to factory.



Display configurations with 8 outputs



Web RCS



- The Web RCS offers a user friendly graphic interface consisting of 3 independent sections: Setup, Edit and Live. A Preconfig. Mode indicates how to easily configure the device step by step.
- With dynamic snapshots of the connected sources available in the interface, the intuitive dashboard allows operators to fully prepare their shows and control them live during their events.
- An innovative sequences mode allows easv organization of presets through drag and drop operation.



* All User Manuals and Quick Start Guides are also available on www. analogway.com

Specifications subject to change without prior notice

All technical specifications are available on our website

Europe, Middle East and Africa - ANALOG WAY SAS - Tel: +33 (0)1 81 89 08 60 / Fax: +33 (0)1 57 19 04 54 / Email: saleseuro@analogway.com The Americas - ANALOG WAY Inc. - Tel: +1 212 269 1902 / Fax: +1 212 269 1943 / Email: salesusa@analogway.com Asia Pacific - ANALOG WAY Pte Ltd - Tel: +65 62 92 58 00 / Fax: +65 62 92 52 05 / Email: sales@analogwayasia.com



LOE032-4K-UK- 07/12/2016